





Flip Lock Instructions

The two keys for your Trunk or Tuckbox can be found inside.

On receiving your item, you may find that the catch is secured.

To open it, turn the outside dial of the lock as shown.



The Trunk or Tuckbox can now be opened by sliding the lock to the left or to the right as shown in this image.

You will find your 2 Flip Lock keys laying inside your new trunk.

Join Us Online.

